

**INTAKE CLEAN****Intake system cleaner  
Aerosol****TYPE OF USE**

Intake manifold and carburettor cleaner especially developed to eliminate deposits and varnishes on butterfly and throttle valves, throttle-chambers, nozzles, bushels, jets, tanks, floats and venturi tubes.

**PERFORMANCES**

MOTUL INTAKE CLEAN stabilizes the idle and improves engine acceleration.

**RECOMMENDATIONS**

Shake before use.

Usage with the engine turned off, disassemble the air filter and spray MOTUL INTAKE CLEAN into the air intake pipe, let stand for 10 minutes. Repeat with the engine turned on by spraying product on nozzles and throttle chambers.

Once intake manifold, carburettor or injection body disassembled:

Spray from a short distance on the areas to be cleaned.

Let stand and re-spray on very dirty areas.

Wipe with a dry piece of fabric.

For 4 Stroke Gasoline engines, complete the operation with MOTUL FUEL SYSTEM CLEAN.